



DOGNESS AUTOMATIC PET PAW CLEANER AND MASSAGER PLUS USER MANUAL



PLEASE READ THE MANUAL CAREFULLY BEFORE USING THE PRODUCT

Thank you for purchasing DOGNESS smart products. For your safety and benefit, please read the product manual carefully before using the product. If you fail to follow the instructions or do not follow the precautions, DOGNESS will not be liable for any personal injury, property or other loss except as expressly provided by law.

ABOUT INSTRUCTION MANUAL

The authorization, trademark and brand name of the manual belong to DOGNESS and other related parties. If the contents of the manual are inconsistent with the actual products, the actual products shall prevail. DOGNESS reserves the right to interpret and modify the instructions within the scope permitted by law. If you have any objection to any content or terms of the instruction manual, please make a written objection to DOGNESS within 7 days after the purchase, otherwise you are deemed to have agreed, understood and accepted all contents of the instruction manual.

CONTENTS

Please check the contents to ensure the following items are included:
Paw Cleaner x 1, USB Cable x 1, Towel x 1, Manual x 1, Warranty Card x 1.

SPECIFICATIONS

Product Name: Dogness Automatic Pet Paw Cleaner And Massager Plus

Model: W02

Size: L 7.0"x W 5.2"x H 7.5"

Weight: 2.09lbs.

Battery Capacity : 2400mAh


Input Voltage: 5V --- 1A

* Requires a 5V/1A USB Power Adaptor.

FEATURES

- 187 Soft Silicone Bristles, provides a deep and thorough cleaning.
- Upgraded design, ideal for larger sized pets.
- Soothing massage, helps to relax the paw muscles as it cleans.
- Two-way rotation for a complete all-around cleaning.
- Dual-Speed, adjustable to the cleaning needs of your pet.
- Built-in Rechargeable battery with USB-C charging, long lasting and high capacity.
- Protects against water and solid objects like dust and sand from entering the electronic components.
- Split independent structure with magnetic inner and outer compartments for easy cleaning.
- Handle design makes it easy to hold and maneuver with less hand fatigue.
- BONUS absorbent towel included to dry the paws after each cleaning.
- Includes: Paw Cleaner, USB-C cable, Towel, Manual and Warranty Card (Power Adapter not included).

PRODUCT OVERVIEW



NOTE: In an effort to provide the best experience for you and your pet, we continually make updates and improvements to our products periodically. This user manual may have slight differences from the actual product.

INSTRUCTIONS FOR USE

1. Fill the cup with an appropriate amount of water and add a few drops of pet safe soap for a more throughout cleaning
2. Insert the pet's paw, push the power button to start the rotation.
 - Press once: Low-speed forward rotation, stops automatically after 10 minutes.
 - Press again: High - speed forward, alternating rotation, stops after 10 minutes.
 - Press again: Power off
3. Dry the pets paw with the included towel or a towel of your own.
4. Discard the dirty water, remove the silicone brush pads and rinse.
 - Refrain from submerging the cup itself into water, Not Dishwasher Safe.
5. If the Cup becomes overloaded (flashing yellow light), lightly press the power button to reset the overload status.

INDICATOR LIGHT DESCRIPTION

| Status | Ready to Use | Insufficient Battery | Charging | Overload Protection | Fully Charged |
|--------|---------------------|---|-------------------|-------------------------|--|
| Color | Green Light (Solid) | When the power button is pressed, the Red light flashes for 5 seconds | Red Light (Solid) | Yellow Light (Flashing) | Green Light (Solid), Turns off when the power cord is unplugged. |

PRECAUTIONS

1. Please charge the product prior to it's initial use.
2. Check the products packaging is intact, and the product, user manual, and warranty card are included and complete.
3. Do not immerse the unit in water, to avoid damage to the battery or the electronic componets.
4. If their are any problems or need help with how to use the device, please contact customer service for assistance, repair or replacement at 833-364-6377 (M-F, 9am-6pm cst) or email: contact@dogness.com.
5. Do not attempt to disassemble or repair. Use this product at your own risk, Dogness is not liable for abnormal operation or irresponsible usage.

***ATTENTION:** The cup body should be cleaned using a dry cloth only. Do not rinse or submerge into water as it could damage or destroy the products electronic components. Indoor Use Only

Entrusting Party: Dogness Group LLC
Address of Entrusting Party: 4116 W Spring Creek Pkwy, Plano, TX 75024
Manufacturer: Jiasheng Enterprise Co., Ltd.
Address of Manufacturer: No. 3 W Yuehua Rd, Tongsha New Industry Park, Dongguan, Guangdong, China 523127
Website: www.dogness.com

| | | | |
|------|-----------------------|------|-----------|
| 名称 | 多尼斯宠物自动洗脚足疗杯产品说明书(英文) | | |
| 文件编号 | JS21MKTPKD221EN | 文件版次 | 5.0 |
| 尺寸 | 270*90mm | | |
| 材质工艺 | 128g哑粉纸 风琴折 | | |
| 设计 | 赖伟全 | 时间 | 2024.1.08 |
| 审核 | | | |